



Bi-Loader Intake Grate **INSTALLATION INSTRUCTIONS**

REQUIRED ITEMS: Marine-grade / mildew resistant silicone
Loctite 572 (blue)

WARNING! DISCONNECT BATTERY AND TURN FUEL OFF BEFORE PERFORMING WORK!

NOTE: IT IS RECOMMENDED THAT YOU WEAR SAFETY GLASSES WHEN PERFORMING THIS TASK

1. Disconnect battery cables from battery and turn fuel cock valve to off position.
2. Apply a generous amount of marine-grade silicone to Riva Bi-Loader Intake Grate-hull mating surfaces (**reference installation images 1-3**).
3. Install intake grate using OE hardware. Torque bolts to 7 Nm (0.7 m • kgf, 5.1 ft • lb). **Use Loctite 572 on bolts.**
4. Remove excess silicone. **NOTE: Do not use chemicals when cleaning silicone.**
5. Inspect intake track for tools, rags, etc and reinstall battery cables.
6. Allow silicone to cure for at least 24 hours.

IMPORTANT: Technical Support

For answers to questions regarding assembly or trouble shooting Riva Yamaha Heavy-Duty Totes contact: Riva Yamaha Tech Line at (954) 247-0705, online at tech_support@rivayamaha.com or you're local Yamaha Dealer.

Riva Yamaha Limited 90-Day Warranty

Riva Yamaha Heavy-Duty Totes carry a 90-day limited warranty to the original purchaser. They are warranted to be free of defects in materials and workmanship under normal use and service. Customer modified components will be void of warranty. This warranty is limited to defects in the primary aluminum components only. Anodized finish, wear marks in or on tote, bunks, wheels and hardware are not covered under this warranty.

Riva Yamaha's liability is expressly limited to the repair or replacement of the aluminum components contained within or associated with this tote. Riva Yamaha agrees to repair or at Riva Yamaha's option, replace any defective unit without charge, if product is returned to Riva Yamaha freight prepaid within the warranty period. Any equipment returned which, in Riva Yamaha's opinion, has been subjected to misuse, abuse, or accident shall not be covered by this warranty.

Riva Yamaha shall have no liability for special, incidental or consequential damages or injury to persons or property from any cause arising from the sale, installation or use of this product.

No other warranty, express or implied, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose, applies. Various states do not allow for the limitation of incidental or consequential damages and therefore the above exclusion or limitation may not apply to you.

Warranty does not include the expenses related to freight or transportation of parts or compensation for any inconvenience or loss of use while being repaired. A copy of the original invoice must accompany all warranty claims.

Warranted replacement parts will be returned freight collect.

Remember the water belongs to everyone!
Please ride responsibly!



Bi-Loader Intake Grate INSTALLATION INSTRUCTIONS

ILLUSTRATION 1




ILLUSTRATION 2




ILLUSTRATION 3

